

Ntgrate wallpaper

HANGING INSTRUCTIONS

Dear customer,

Thank you for choosing ntgrate. With a woven vinyl fabric wallpaper you protect the walls of your house, making them resistant to knocks and scratches. Furthermore, the wallpaper is easy to maintain.

Introduction

Ntgrate wallpaper must be put up by a professional who has experience in putting up heavy fabric wall hangings. Putting up fabric wall hanging is very similar to putting up normal wallpaper. The instructions below will help you to create beautiful, durable walls.

Preparation

1. The room where the wallpaper is being hung should be neither too warm nor too damp.
The temperature should preferably be between 18 and 25 °C.
2. Avoid quick warming or cooling of the room when the wallpaper is being hung, and afterwards when it is drying
3. Make the walls dry, smooth, clean, dust-free and grease-free
4. Close any holes and/or cracks in the wall with a filler and sand them down so they are smooth
5. If the walls are very absorbent or porous, such as plaster or plasterboard, it is advisable to first treat them with a wall sealer. A primer, size, or an undercoat is always recommended. The undercoat will ensure better adhesion
6. Lay out all the rolls of wallpaper in order. Each roll is labelled with the batch number and has a unique number (roll 1, roll 2, etc).

Hanging

1. Cut a few strips of woven vinyl wallpaper to the desired length. Measure the height of the wall and add 10 cm extra (5 cm above and 5 cm below).
2. Roll up the wallpaper with the pattern (with the woven vinyl) on the inside.
3. The best place to start is a distance of 95 cm from the corner of the room (with sheets that are 100 cm wide).
4. Hang a plumb line 95 cm from the corner where you are starting.
5. Paste the walls with an all-purpose, ready-to-use wallpaper adhesive for fabric and textile wallpaper (acrylate-based) (follow the instructions from the adhesive manufacturer).
Apply the adhesive to the wall with a long-haired roller. Do this for the width of 1 strip, reduced by a few cm on the side where the next sheet will be hung.
Spread the adhesive as equally as possible. It is best to apply adhesive to corners and sides with a flat brush. The required wall surface must be coated with adhesive as equally as possible, to prevent air bubbles from forming afterwards.

6. Hang the first sheet of wallpaper perfectly next to the plumb line and away from the corner. Ensure that you have about 5 cm extra wallpaper at the top and at the bottom. Press down well with a spatula. With the spatula, you can get rid of any creases or bubbles that appear by pushing them to the (free) side, top or bottom, until you have a sheet that is nicely flush against the wall.
7. Cut away the extra fabric from the ceiling and skirting boards with a sharp snap-off Stanley knife. You are recommended to break off a piece of the blade after hanging each sheet of wallpaper.
8. You can easily get rid of loose pieces of fabric wallpaper with a sharp pair of scissors.
9. For the first sheet, make the side next to the plumb line loose again down the whole length, for a width of approximately 5 cm.
10. Apply adhesive equally to the full side, to the corner.
11. Press the piece of the pasted sheet that has made loose back into place with a spatula.
12. Hang the second sheet from the corner up to a distance of approximately 1 mm from the first sheet and then push horizontally to the join, so it closes. Then press down the whole sheet with a spatula. Cut the extra wallpaper from the top, bottom and the corner with a sharp, snap-off knife.
13. Roll the join flat with a hard seam roller.
14. Put the next sheet approximately 1 mm from the other side of the previous sheet. Apply the adhesive to the wall over the width of the sheet.
15. Hang the following sheet approximately 1 mm from the last sheet, and then press the join horizontally until it is closed.
16. Press down the full sheet and also the loose side of the first hung sheet with a spatula.
17. Roll the join flat with a hard seam roller.
18. Repeat this method as described above (steps 14-17) until the desired space has been covered in wallpaper.
19. Allow everything to dry properly.

Things to be aware of

1. Check the result after putting up 3 sheets. Complaints about more than 3 sheets will not be accepted. If there is further deviation, it is your own responsibility. Complaints must be reported to your dealer immediately and directly. We advise you to employ an experienced professional to hang the wallpaper.
2. Ntgrate wallpaper that has been put up in the correct way can be simply removed, dry.
3. Woven vinyl wallpaper can be brushed or vacuumed. Stubborn stains are best removed with a wet cloth.
4. Ntgrate wallpaper is not suitable for outdoor applications.

Don't hesitate to speak with your ntgrate contact person if you have any questions or comments.

NTGRATE'S GUARANTEE OF PARTIAL/FULL REFUND OR REPLACEMENT IN THE EVENT OF A FAULT IS INVALID IF THE ABOVE INSTRUCTIONS HAVE NOT BEEN STRICTLY FOLLOWED.